



hardware module (dongle)

## Heraeus Noblelight Light Hammer 6 & 10 MARK II System Monitoring Software

### **Minimize unscheduled system shutdowns using the Heraeus Noblelight On-Board System Monitoring software**

Heraeus Noblelight's new on-board system monitoring software, Advanced Integrated Monitoring System (AIMS) MARK II, is now available for the Light Hammer 6 & 10 MARK II Systems. This new software application provides real-time system performance monitoring for the Light Hammer 6 & 10 MARK II. Through the use of a proprietary communication network, many of the system performance metrics can now be monitored by a PC connected to the network.

## Key Features

- One tool to record, monitor, and maintain the entire system performance parameters
- Tracking of operational hours by key components – magnetron, bulb, and reflector hours
- Capable of monitoring 24 different system metrics including magnetron current, magnetron voltage, photocell voltage, and more
- Can send email alert when warnings/faults occur
- Ability to log data in 15, 30, or 60-second intervals
- Automatically creates a new data file at midnight with date stamp. If enabled, the data file can be sent automatically via email.
- Each data point provides min., max., std. deviation, and mean for the period
- User-friendly and flexible software
- Single cable connects from the proprietary Light Hammer MARK II network to USB port on PC
- Display up to 6 user-selectable metrics simultaneously on display screen
- Can display data in graph, gauge, or text formats
- Network available via Master/Slave port (J102)
- Can periodically email System Summary Report

## Operating Parameters

- Consists of hardware module (dongle) and a PC software application
- Requires a PC or laptop for software application


A DeviceNet™ network is no longer required to operate the AIMS MARK II software.



Graph View



Gauge View



Text View

### heraeus-noblelight.com

Germany

#### Heraeus Noblelight GmbH

Heraeusstraße 12-14

63450 Hanau

Phone +49 6181 35 4499

Fax +49 6181 35 9926

hng-uv@heraeus.com

USA

#### Heraeus Noblelight America LLC

910 Clopper Road

Gaithersburg, Maryland

20878-1357

Phone +1 301 527 2660

Fax +1 301 527 2661

info.hna.uvp@heraeus.com

Japan

#### Heraeus K.K.

Noblelight Division

Sumitomo Fudosan Otowa

Building 1F, 2F, 5F

2-9-3 Otsuka, Bunkyo-ku

112-0012, Tokyo

Phone +81 3 6902 6602

Fax +81 3 6902 6613

info.hkk@heraeus.com

China

#### Heraeus Noblelight (Shenyang) Ltd.

Shanghai Branch

2F, 5th Building, No. 406 Guilin Rd

Xuhui District

Shanghai 200233, P.R. China

Phone +86 400 080 2255

Fax +86 21 3357 5333

info.hns@heraeus.com

ISO 9001 Certified QMS

